



BG: ФУНКЦИИ И ИНСТРУКЦИИ ЗА БЕЗОПАСНА УПОТРЕБА И ПОДДРЪЖКА НА ДЕТСКИ КОЛАН ЗА ПРОХОЖДАНЕ „WALKY”, АРТИКУЛЕН НОМЕР BW001

ВАЖНО! ПРОЧЕТЕТЕ ВНИМАТЕЛНО И ЗАПАЗЕТЕ ЗА БЪДЕЩИ СПРАВКИ.

ВНИМАНИЕ!

1. Коланчето за прохождение е предназначено за употреба от деца на възраст от 6 до 24 месеца и с максимално тегло до 20 кг.
2. Следвайте стриктно препоръките и предупрежденията за безопасно употреба на продукта.
3. Внимание! Никога не оставяйте детето без надзор докато носи колана за прохождение.
4. Внимание! Бъдете особено внимателни, когато използвате колана за прохождение в близост до автоматични врати, ескалатори и др.
5. Когато не използвате коланчето за прохождение, го съхранявайте далеч от достъпа на деца.
6. Презрамките и катарамите трябва редовно да се проверяват за износване и възможна повреда.
7. Спрете да използвате коланчето за прохождение, ако то е повредено, има счупени токи или липсващи и скъсани части (презрамки, ремъци)
8. Проверявайте редовно дали детето е добре обезопасено и се чувства удобно, използвайки коланчето.
9. Винаги проверявайте дали катарамата и закопчалките са добре затворени и дали ремъците са правилно нагласени и пригодени.
10. Запазете опаковката за бъдеща справка. Съдържа важни инструкции и предупреждения за безопасната употреба на продукта.

ПОСТАВЯНЕ НА КОЛАНЧЕТО: Промушете ръцете на детето през презрамките на колана за прохождение. Поставете колана за прохождение около гръдния кош на детето. Залепете велкро лепенката. Закопчайте катарамата и пристегнете коланчето така, че да прилегне плътно към детето без това да му причинява неудобство. Регулирайте дължината на раменните ремъци до желаната и удобна за детето и Вас позиция, закопчайте катарамата. Чрез родителската дръжка можете да придържате детето при прохождение.

УКАЗАНИЯ ЗА ПОЧИСТВАНЕ И ПОДДРЪЖКА:

1. Почиствайте коланчето за прохождение редовно, за да отстраните замърсените участъци и да удължите употребата на продукта.
2. Не перете в перална машина. Почиствайте на ръка в разтвор от топла вода и мек почистващ препарат. Изплъкнете добре, като внимавате по токите и коланчетата да не остане сапун или друг почистващ препарат. Не използвайте химическо чистене, омекотители, белина или почистващи препарати на спиртна основа или с абразивни частици. Оставете коланчето да изсъхне напълно преди употреба. Не използвайте сушилни за тази цел. Абсолютно забранено е гладенето, на която и да е част от коланчето.
3. Съхранявайте продукта на сухо и чисто място, далеч от пряка слънчева светлина и извън обсега на деца.

Продуктът отговаря на изискванията за безопасност на европейския стандарт: EN 13210-1:2020 “Изделия за отглеждане на малки деца. Част 1: Детски колани и каишки за прохождение. Изисквания за безопасност и методи за изпитване”

Произведено за CANGAROO в КНР

Производител и Вносител: Мони Трейд ООД

Адрес: България, София,

Кв. Требич, ул. Доло 1

Тел: +359 2 936 07 90



EN: CHILD WALKING BELT "WALKY" FUNCTIONS AND INSTRUCTIONS FOR SAFE USE AND MAINTENANCE, ITEM NUMBER BW001
IMPORTANT! READ CAREFULLY AND KEEP FOR FUTURE REFERENCE.

WARNING!

1. The baby walker is intended for use by children from 6 till 24 months of age with maximum weight of 20 kg.
2. Follow strictly the recommendations and warnings for the safe use of the product.
3. Warning! Never leave your child unattended whilst wearing a harness.
4. Warning! Be aware of the danger when using reins near automatic doors, escalators, etc.
5. When the baby walker is not in use keep it out of child's reach.
6. Straps and buckles should be checked regularly for excessive wear and possible damage.
7. Stop using the baby walker, if it is damaged, there are broken buckles and parts that are torn apart (harnesses, belts).
8. Check regularly if the child is well secured and feels comfortable using the baby walker.
9. Always check that the buckle and clasps are properly closed and that the straps are properly adjusted and fitted.
10. Keep the package for future reference. It contains important instructions and warnings for the safe use of the product.

PLACING THE BABY WALKER: Put the arms of the child through the shoulder straps of the walking belt. Put the walker around the child's chest. Attach the Velcro strap. Engage the buckle of the belt and tighten the belt so that the walker can fit snugly around the child without causing any discomfort. Adjust the length of the shoulder straps to a position that is comfortable for the child and you. By the parent handle you can hold the child when walking.

INSTRUCTIONS FOR MAINTENANCE AND CLEANING:

1. Clean the baby walker regularly in order to remove the dirty spots and prolong the use of the product.
2. Do not wash in a washing machine. Wash by hand with warm water and mild cleanser. Rinse thoroughly and be careful not to leave any soap or other cleanser on the buckles and belts. Do not use dry cleaning, softeners, bleach or alcohol-based detergents or such with abrasive particles. Leave the baby walker to dry completely before usage. Do not use dryers. Do not iron any of the parts of the baby walker.
3. Store the product in a dry and clean place away from direct sunlight and away from children's reach.

The product complies with the safety requirement of the European standard EN 13210-1:2020 "Child care articles - Part 1: Children's harnesses, reins - Safety requirements and test methods"

Manufactured for CANGAROO in CNR

Manufacturer and Importer: Moni Trade Ltd.

Address: Bulgaria, Sofia,

Trebich, 1 Dolo str.

Tel: +359 2 936 07 90